



## INSTRUCTIONS

1. Using sharp modeler's knife or fine toothed razor saw, **CUT** parts from sprues — **DO NOT BREAK.**
2. Install couplers (not included) and cement pocket covers in place.
3. To install trucks (not included) using truck pins, drive pins through truck bolsters and into snaps on frame like small nails. Trucks can then be snapped on or off.
4. If truck pins are used, remove truck mount bosses from floor before cementing frame to floor. If trucks are to be installed with #2 screws, (not included) **DO NOT REMOVE** truck mount bosses from floor.
5. Cement triple valve to frame as shown.

## NOTE:

The brake platform, chain, and housing are extremely delicate and may break at the chain during handling. They can be butted together and rejoined with cement when application to car is done.