



RAF Bristol Blenheim Mk.I/Mk.If





For the best results these decals should be applied to a gloss surface such as provided by either Xtracolor or Xtracrylix paints. Cut out the decal required and soak in warm water until the decal is released from the backing paper. Wet the area to be decaled with MICRO SET which will help to eliminate air trapped under the decal and position the decal.

After 5 or 10 minutes wet the decal with MICRO SOL which will soften the decal and ensure that it settles down over any surface detail. Allow the decal to dry for at least 12 hours. During this time some wrinkling of the decal may occur, this is normal. Do not touch the decal at this time.

Carefully check for small air bubbles and if there are any prick with a needle and apply a drop of MICRO SOL. After all air bubbles have been eliminated and the decals are dry wash the entire model with water to remove any excess decal adhesive.

When completely dry the whole model should be sprayed with a coat of Xtracolor or Xtracrylix Flat, Satin or Gloss varnish depending on the finish required.

Store in a cool dry place, avoid sunlight, dampness or extremes of temperature and/or humidity.




www.hannants.co.uk


Harbour Road, Oulton Broad, Lowestoft, Suffolk, NR32 3LZ

Phone +44 1502 517444

+44 1502 500521

sales@hannants.co.uk







X72298=>
TRADECAL
Website
www.hannants.co.uk


Bristol Blenheim Mk.If, serial unknown, 'WQ.P' of 604 Squadron, Royal Air Force based at RAF Hendon, Middlesex, N UK, Spring, 1939.

'WQ.P' was finished in
Dark Green & Dark Earth over
Night undersides but with the starboard
wing and tailplane being White
with a Night engine





Bristol Blenheim Mk.I, L1381, 'VA.G of 113 Squadron, Royal Air Force, based in Greece, 1941.







Bristol Blenheim Mk.If, L6782, 'ZD.A' of 222 Squadron, Royal Air Force, based at RAF Duxford, Cambridgshire, 1940.




















Xtracolor Paints

X001 Dark Green X002 Dark Earth X009 Middle Stone X012 Night X026 Azure Blue X141 White

The colours used on these aircraft can be found in the Xtracolor (prefix number with X) and Xtracrylix (prefix number with XA1) range of paints.

Paints:

Xtracrylix Paints

XA1001 Dark Green XA1002 Dark Earth XA1009 Middle Stone XA1012 Night XA1026 Azure Blue XA1141 White